



## SYSTEM HISTORY

	<i>Models</i>		start	end
"Classic"	P46	Proengin	1980	1984
	P31 / P40 / P52	Profurl / Proengin	1984	1987
	N/L31 - N/L42	Profurl	1988	1993
	N/L52	Profurl	1988	2006
	N70 - P95	Profurl / Proengin	1989	2006
"Basic"	B29 / B35	Profurl	1989	2006
	S 26	Profurl	1991	1999
	NC / LC	Profurl	1994	2006
	T26	Profurl	1999	2006